

NuBEAM 1000 μm Core Beam Delivery Fiber



Coherent's beam delivery NuBEAM specialty multimode step-index fibers are designed for compatibility with the majority of fiber interconnect systems and diode laser power delivery systems. This fiber features a 1000 micron core diameter, 0.22 NA and 1100 micron clad diameter with a silicone coating and a transparent nylon buffer. This fiber is also available with Coherent's proprietary NuCOAT-FA coating for added power confinement or polyimide for high temperature applications. Additional clad diameters and different NAs are available upon request.

Typical Applications

- Fiber coupled diode lasers
- Couplers and pump combiners
- Beam delivery cables
- Spectroscopy and instrumentation

Features & Benefits

- Robust industry standard design — Compatible with majority of fiber interconnect systems
- Exceptional geometric uniformity and core/clad concentricity — Ease of assembly
- Clean room fiber draw — Eliminates coating "hot spots"
- Pure Silica Core — High resistance to optical damage

Optical Specifications

Operating Wavelength	800 – 2100 nm
Core NA	0.220 \pm 0.020
OH Level	Low

Geometrical & Mechanical Specifications

Cladding Diameter	1122.0 \pm 22.0 μm
Core Diameter	1020.0 \pm 20.0 μm
First Buffer Diameter	1200.0 \pm 36.0 μm
Second Buffer Diameter	1400 \pm 70 μm
First Buffer Material	Silicone
Second Buffer Material	Transparent Nylon
Short Term Bend Radius	\geq 110 mm
Long Term Bend Radius	\geq 330 mm
Proof test Level	\geq 70 kpsi (0.5 GN/m ²)

BD-S1000/1100-STN



Buffer Requirements: Silicone Primary Buffer, Transparent Nylon Outer Buffer
 Low or High -OH Core: Low
 Matched or Depressed Cladding: Depressed
 Special Core Dopants: Pure Silica Core

Nufern • 7 Airport Park Road, East Granby, CT 06026 • 860.408.5000 • Toll-free 866.466.0214 • Fax 860.844.0210 • Email: tech.sales@coherent.com
 www.coherent.com ; www.shop.coherent.com • Coherent products are manufactured under an ISO 9001:2008 certified quality management system.



Custom developed fiber (FUD) specifications are subject to change without notice. Other configurations such as alternative form factors, optimized cut-off and UV cured color coating may be available. Let us know how Coherent can assist with your requirements.