

Ytterbium-Doped Single-Mode Single Clad Fiber



Coherent single-mode Yb-doped fibers are designed to support low power fiber lasers and amplifiers based on single-mode diode pump technology, rather than the multimode pumps used in high-power applications. For applications where high efficiency and very short device lengths are critical, these single-mode fibers are compatible with standard "telecom" fiber technology ensuring low splice loss to numerous fiber pigtailed components. The PM variety is designed with the PANDA-style stress structure which delivers linearly polarized light suitable for frequency conversion. These fibers make the ideal gain medium for low average power femtosecond fiber lasers and pre-amplifiers for higher power double-clad amplifiers. These High Performance (-HP) versions provide tighter optical and geometric tolerances, improving device performance, system compatibility and manufacturing process control.

Typical Applications

- Low power CW and pulsed fiber lasers
- Femtosecond fiber lasers
- Pre-amps for high-power, double-clad devices

Features & Benefits

- Single-mode output — Compatible with standard telecom 980/1060 nm fiber-based components with low splice loss
- PANDA-style stress structure — Linearly polarized output for frequency conversion
- High Ytterbium concentration — Short fiber lengths to reduce detrimental non-linear effects
- High slope efficiency (typically 75%) — Efficient utilization of pump power
- Higher Proof-test Yields — Critical for long-term reliability in tight bend applications

Optical Specifications

	PM-YSF-HI-HP	SM-YSF-HI-HP	PM-YSF-LO-HP	SM-YSF-LO-HP
Operating Wavelength	1015 – 1115 nm	1015 – 1115 nm	1015 – 1115 nm	1015 – 1115 nm
Core NA	0.110	0.110	0.130	0.130
Mode Field Diameter	7.5 ± 0.7 μm @ 1060 nm	7.5 ± 0.7 μm @ 1060 nm	6.5 ± 0.7 μm @ 1060 nm	6.5 ± 0.7 μm @ 1060 nm
Cutoff	860 ± 50 nm	860 ± 50 nm	860 ± 50 nm	860 ± 50 nm
Core Attenuation	≤ 10.0 dB/km @ 1200 nm	≤ 10.0 dB/km @ 1200 nm	≤ 10.0 dB/km @ 1200 nm	≤ 10.0 dB/km @ 1200 nm
Core Absorption	85.0 ± 10.0 dB/m at 915 nm 250.0 dB/m at 975 nm	85.0 ± 10.0 dB/m at 915 nm 250.0 dB/m at 975 nm	26.0 ± 4.0 dB/m at 915 nm 80.0 dB/m at 975 nm	26.0 ± 4.0 dB/m at 915 nm 80.0 dB/m at 975 nm
Birefringence	> 2.8 × 10 ⁻⁴	N/A	> 2.8 × 10 ⁻⁴	N/A

Geometrical & Mechanical Specifications

	PM-YSF-HI-HP	SM-YSF-HI-HP	PM-YSF-LO-HP	SM-YSF-LO-HP
Cladding Diameter	125.0 ± 1.0 μm	125.0 ± 1.0 μm	125.0 ± 1.0 μm	125.0 ± 1.0 μm
Core Diameter	6.0 μm	6.0 μm	5.0 μm	5.0 μm
Coating Diameter	245.0 ± 10.0 μm	245.0 ± 10.0 μm	245.0 ± 10.0 μm	245.0 ± 10.0 μm
Coating Concentricity	< 5.0 μm	< 5.0 μm	< 5.0 μm	< 5.0 μm
Core/Clad Offset	≤ 0.50 μm	≤ 0.50 μm	≤ 0.50 μm	≤ 0.50 μm
Coating Material	Acrylate	Acrylate	Acrylate	Acrylate
Operating Temperature Range	-55 to 85 °C	-55 to 85 °C	-55 to 85 °C	-55 to 85 °C
Proof-test Level	≥ 200 kpsi (1.4 GN/m ²)	≥ 200 kpsi (1.4 GN/m ²)	≥ 200 kpsi (1.4 GN/m ²)	≥ 200 kpsi (1.4 GN/m ²)



The passive version of each fiber is also available (1060-XP, PM980-XP, and photosensitive PS1060, PS-PM980)
Estimated 915 nm absorption based on measured absorption curve @ 950 nm and 1010 nm for fibers PM-YSF-HI-HP and SM-YSF-HI-HP

Nufern • 7 Airport Park Road, East Granby, CT 06026 • 860.408.5000 • Toll-free 866.466.0214 • Fax 860.844.0210 • Email: tech.sales@coherent.com
www.coherent.com ; www.shop.coherent.com • Coherent products are manufactured under an ISO 9001:2008 certified quality management system.



Custom developed fiber (FUD) specifications are subject to change without notice. Other configurations such as alternative form factors, optimized cut-off and UV cured color coating may be available. Let us know how Coherent can assist with your requirements.